



JOINT REPAIR - WALL TO SLAB (INBOARD)

REFER TO APPLICATION INSTRUCTION 5.12